DART SERVICE INSTRUCTION

TO AMEND INSTALLATION INSTRUCTIONS IIN-D119-675 REV. B AND INSTRUCTIONS FOR CONTINUED AIRWORTHINESS ICA-D119-675 REV. 2

REF. FAA STC SR00948SE & EASA STC EASA.IM.R.S.01458

1.0 INTRODUCTION:

The purpose of this Service Instruction is to improve installation of D119-675-011/-012 *Heli-Access-Steps*. This improvement consists of replacing the inboard D3042-1 Clamps and D2182B032 Rubber Cushions with D3041-5/-7 Clamps and D2732-032 Rubber Cushions.

For existing installations (D119-675-011/-012 *Heli-Access-Steps* @ Change 004 or earlier), this service instruction also recommends removal of the D2617-5 Bushings at the aft crosstube position to prevent the bearings in the D3041-1/-3 clamps from being pushed out and makes it permissible for operators to raise the step an additional 2.00 inches (51mm) to provide clearance for the ground handling wheels. Refer to section 2.0 of this Service Instruction.

New installations steps (D119-675-011/-012 *Heli-Access-Steps* @ change 005 or later) will have their parts list and instructions amended accordingly. Refer to section 3.0 of this Service Instruction.

2.0 INSTALLATION OF DSI 9647-011 CLAMP REPLACEMENT KIT:

- 2.1 The DSI 9647-011 Clamp Replacement Kit can be procured from Dart. One kit upgrades one step.
- 2.2 Remove and discard the D3042-1 Clamps, D2182B032 Rubber Cushions and hardware. Replace with the D3041-5/-7 Clamps, D2732-032 Rubber Cushions and hardware as shown in Section B-B and C-C of this Service Instruction.
- 2.3 Tighten clamp bolts. Do not exceed torque of 60 in-lb (6.8 nm) on the nuts. **CAUTION:** Over-torquing the nuts could lead to structural damage of the clamps.
- 2.4 Amend weight and balance per section 4.0 of this Service Instruction.

Α	NEW IS	SSUE		AJS	13.04.04
REV.			DESCRIPTION	BY	DATE
DESIGN		AJS	DART AEROSPACE USA, INC		
DRAWN AJS		AJS	KENT, WA		
CHECKED		_\$	DRAWING NO.		REV. A
MFG. APPR.		N/A	DSI 9647		SHEET 1 OF 6
APPROVED		129	TITLE		SCALE
DE APPR.			CLAMP REPLACEMENT N		NTS
13.04.04			COPYRIGHT © 2013 BY DART AEROSPACE USA, INC THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISION FROM DART AEROSPACE USA, INC.		

3.0 INSTALLATION INSTRUCTIONS:

For D119-675-011/-012 Heli-Access-Steps @ CHG 005 or later.

Step installations for the A119/AW119 MKII rotorcraft are illustrated in Figure 1 and View A-A, Sections B-B, and C-C of this Service Instruction.

- 3.1 Remove the existing crosstube-mounted short steps.
 - a) For **A119 model** aircraft, remove the Agusta P/N 109-0570-33-101/-103 step by drilling out the 4 attachment rivets per step. Plug holes with rivets and touch up paint per the Aircraft Maintenance Manual as required.
 - b) For **AW119 MKII model** aircraft, remove the Agusta P/N M031-01S002-041 step by removing the MS21920-20/-22 clamps. Touch up paint per the Aircraft Maintenance Manual as required.

NOTE: It is acceptable to leave the short steps on the landing gear provided they do not interfere with the installation of the Dart step in accordance with the dimensions shown in View A-A of Figure 1.

- 3.2 Install the D3041-1/-3 Clamps on the step as follows.
 - a) For A119 model aircraft, install the D3041-1/-3 Clamps per Sections B-B and C-C of this Service Instruction.
 - b) For AW119 MKII model aircraft, install the D3041-1 Clamps per Sections B-B and C-C of this Service Instruction.
- 3.3 Present the step to the outboard side of the crosstubes. Propping the step at the appropriate height (see Figure 1) can facilitate installation.
- 3.4 Install the D2732-032 Rubber Cushions under the D3041-1/-3/-5/-7 Clamps (see Sections B-B and C-C (of this DSI)).
- 3.5 Find the appropriate step height by locating the step/clamp as shown in View A-A. Locate the forward D3041-1/-3 Clamp 7.8"- 10.4" above the crosstube cuff. Locate the aft D3041-1 Clamp 7.8"-11.6" above the crosstube cuff. The distances given are from the crosstube cuff to the bottom-most clamp.
- 3.6 Tighten the clamp bolts. Do not exceed torque of 60 in-lb (6.8 Nm) on the nuts.
 CAUTION: Over-torquing the nuts could lead to structural damage of the clamps.
- 3.7 Amend weight and balance per section 4.0 of this Service Instruction.

DESIGN AJS		DART AEROSPACE USA, INC		
DRAWN	SلږA	KENT, WA		
CHECKED	_\$	DRAWING NO.	REV. A	
MFG. APPR.	N/A	DSI 9647	SHEET 2 OF 6	
APPROVED	149	TITLE	SCALE	
DE APPR.		CLAMP REPLACEMENT	NTS	
13.04.04		COPYRIGHT © 2013 BY DART AEROSPACE USA, INC THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.		

4.0 WEIGHT AND BALANCE:

Use the following Weight and Balance for D119-675-011/-012 @ CHG 005 or later.

		LATERAL		LONGITUDINAL	
Installation	Weight	Arm	Moment	Arm	Moment
D119-675-011	11.8 lb	-32.4 in	-382 in-lb	121.3 in	1431 in-lb
Heli-Access-Step™, LH	5.4 kg	-1.28 m	-6.9 m-kg	3.08 m	16.6 m-kg
D119-675-012	11.8 lb	+32.4 in	+382 in-lb	121.3 in	1431 in-lb
Heli-Access-Step [™] , RH	5.4 kg	+1.28 m	+6.9 m-kg	3.08 m	16.6 m-kg


5.0 PARTS LISTS:


QTY -011	Part Number	Description
Х	DSI 9647-011	CLAMP REPLACEMENT KIT
4	D2732-032	RUBBER CUSHION
4	D3041-5	CLAMP
2	D3041-7	CLAMP
8	AN4-16A	BOLT
8	AN960JD416	WASHER
8	MS21042L4	BOLT


Use the following Parts List for D119-675-011/-012 @ CHG 005 or later.

Qty -011	Qty -012	Part Number	Description
Х		D119-675-011	HELI-ACCESS-STEP™, LH
	Х	D119-675-012	HELI-ACCESS-STEP™, RH
8	8	D2274	RADIUS BLOCK
4	4	D2617-3	BUSHING
4	4	D2617-5	BUSHING
8	8	D2732-032	RUBBER CUSHION
4	4	D3041-1	CLAMP
2	2	D3041-3	CLAMP
4	4	D3041-5	CLAMP
2	2	D3041-7	CLAMP
1		D3043-041	STEP WELDMENT LH
	1	D3043-042	STEP WELDMENT RH
4	4	AN4-15A	BOLT
8	8	AN4-16A	BOLT
12	12	AN960JD416	WASHER
12	12	MS21042L4	NUT (OR MS21042-4)


DESIGN AJS DRAWN AJS		DART AEROSPACE USA, INC	
CHECKED	_A	DRAWING NO.	REV. A
MFG. APPR.	N/A	DSI 9647	SHEET 3 OF 6
APPROVED	NO	TITLE	SCALE
DE APPR.		CLAMP REPLACEMENT	NTS
DATE 13.04.04		COPYRIGHT © 2013 BY DART AEROSPACE USA, INC THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WINDSTEIN PROVINCE AND ART AEROSPACE USA INC.	








DESIGN	AJS	DART AEROSPACE USA, INC KENT, WA	
DRAWN	ĄJS		
CHECKED	Js	DRAWING NO.	REV. A
MFG. APPR.	N/A	DSI 9647	SHEET 5 OF 6
APPROVED	1:9	TITLE	SCALE
DE APPR.	-##	CLAMP REPLACEMENT	NTS
13.04.04		COPYRIGHT © 2013 BY DART AEROSPACE USA, INC THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.	





DESIGN	AJS	DART AEROSPACI	USA, INC
DRAWN	ĄJS	KENT, WA	
CHECKED	_k	DRAWING NO.	REV. A
MFG. APPR.	N/A	DSI 9647	SHEET 6 OF 6
APPROVED	143	TITLE	SCALE
DE APPR.		CLAMP REPLACEMENT	NTS
DATE 13.0)4.04	COPYRIGHT © 2013 BY DART AEROSPACE USA, INC THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WITH THE PREMISSION FROM DATA PERSOPACE (15A INC.)	